



ABU BC MAX DLC BG H 31 00
1547075 34-13719-0

パーツID	パーツ名	価格
1	1553502 FRAME	¥4,000
2	1529304 LIFT CURVE	¥300
3	1529305 KICK LEVER	¥300
4	1529306 CLUTCH SPRING	¥200
5	1529147 KICK LEVER SPRING	¥200
6	1529308 LIFT CURVE PLATE	¥300
7	1548309 SCREW	¥200
8	1529148 SCREW	¥200
9	1529310 THUMB BAR	¥300
10	1125962 SCREW (C)	¥160
11	1529311 WORM SHAFT PIN	¥200
12	1529312 WORM SHAFT GEAR	¥200
13	1529313 WORM SHAFT	¥1,500
14	1529314 LINE GUIDE TUBE	¥300
15	1553503 LINE GUIDE	¥500
16	1529316 WORM SHAFT BUSHING	¥200
17	1206522 RETAINER	¥200
18	1206527 PILOT GUIDE	¥200
19	1529204 WASHER	¥200
20	1529317 LINE GUIDE NUT	¥200
21	1529318 LINE GUIDE SHAFT	¥500
22	1513272 SCREW	¥200
23	1553504 FRONT COVER	¥500
24	1529321 RETAINER	¥200
25	1529322 BUSHING	¥200
26	1529323 MAIN GEAR SHAFT PLATE	¥300
27	1548128 SCREW	¥200
28	1529324 MAIN GEAR SHAFT	¥1,000
29	1529325 RATCHET	¥300
30	1529326 STOPPER	¥500
31	1529327 LEVEL WIND GEAR SHAFT	¥300
32	1529328 LEVEL WIND GEAR	¥200
33	1529329 BUSHING	¥200
34	1529330 SCREW	¥200
35	1529331 YOKE	¥200
36	1529332 YOKE SPRING	¥200
37	1553567 PINION	¥1,000
38	1529334 DRAG WASHER	¥300
39	1529335 WORM SHAFT DRIVE GEAR	¥500
40	1553568 MAIN GEAR	¥1,500
41	1529228 CLICK SPRING	¥300
42	1529229 SCREW	¥200
43	1529337 WASHER DRUM	¥400
44	1529338 DRAG WASHER	¥500
45	1553507 METAL WASHER	¥300
46	1529341 ONE WAY CLUTCH ASSEMBLY	¥1,200
47	1553569 GEAR SIDE PLATE	¥2,500
48	1529236 BALL BEARING	¥2,500
49	1513276 RING	¥200
50	1538274 O-RING	¥200
51	1513278 FRICTION WASHER	¥200

パーツID	パーツ名	価格
52	1529344 CLICKER	¥200
53	1553559 BRAKE KNOB	¥1,000
54	1529234 FLIPPING SWITCH	¥300
55	1529240 SCREW	¥200
56	1529270 LINE GUIDE SHAFT	¥300
57	1538275 BALL BEARING	¥600
58	1553560 SPOOL ASSEMBLY	¥4,000
59	1553561 SPOOL	¥2,000
60	1530654 BALL BEARING	¥600
61	1530655 PIN	¥200
62	1529349 CLICK GEAR	¥300
63	1529218 MAGNET	¥200
64	1529219 MAGNET BALANCE	¥200
65	1341547 SPOOL CLICKER SPRING SCREW	¥200
66	1553562 ELECTRONIC LINE COUNTER	¥5,000
67	1553563 BATTERY DOOR	¥500
68	1456426 O-RING	¥200
69	1529214 SCREW	¥200
70	1529212 BALL BEARING	¥600
71	1130070 BRONZE WASHER (C)	¥160
72	1529351 BB HOLDER	¥1,500
73	1529283 SCREW	¥200
74	1553563 LINE CLIP	¥200
75	1529354 PALM SIDE PLATE	¥2,000
76	1529207 SCREW	¥200
77	1529220 SCREW	¥200
78	1529355 WASHER	¥200
79	1529356 SPRING WASHER	¥200
80	1529357 CLICK SPRING HOLDER	¥200
81	1529358 CLICK SPRING	¥200
82	1529359 SPRING WASHER	¥200
83	1553564 STAR WHEEL	¥1,200
84	1529361 WASHER	¥200
85	1553565 HANDLE ASSEMBLY	¥3,000
86	1553566 HANDLE ARM	¥1,000
87	1275802 HANDLE KNOB BUSHING	¥200
88	1531321 HANDLE KNOB	¥800
89	1518224 SCREW	¥200
90	1531322 HANDLE KNOB CAP	¥600
91	1529363 WASHER	¥200
92	1529364 HANDLE NUT	¥200
93	1513293 SCREW	¥200